



# Separation System



The Separation System, proposed by Brevetti Stendalto, guarantees the perfect disposal of cables inside the chain and allows an easy opening of the frame also when the chain is already harnessed. A wide range of horizontal separators is available in order to obtain many different arrangements.



Horizontal Separator Part Number	X mm	$\frac{X}{2}$
SO01016	16	
SO01025	25	
SO01029	29	
SO01035	35	
SO01041	41	SO01016 + S... + SO01016
SO01050	50	SO01016 + S... + SO01025
SO01059	59	SO01025 + S... + SO01025
SO01066	66	SO01029 + S... + SO01029
SO01074	74	SO01025 + S... + SO01041
SO01091	91	SO01041 + S... + SO01041
SO01108	108	SO01059 + S... + SO01041
SO01120	120	
SO01140	140	SO01091 + S... + SO01041


## 445MU/PU/AU

Side separator. Halfway mobile separator. Halfway separator. Horizontal separator. Up to 4 horizontal separations.




## 770A

Side separator. Halfway separator. Horizontal separator. Up to 4 horizontal separations.




## 660A - 306SU/CU - 326SU

Side separator. Halfway separator. Halfway mobile separator. Horizontal separator. Up to 2 horizontal separations.




## 308SU/CU - 328SU

Side separator. Halfway separator. Halfway mobile separator. Horizontal separator. Up to 4 horizontal separations.




## 307SU

Side separator. Halfway separator. Horizontal separator. Up to 4 horizontal separations.




## 80PU

Side separator. Halfway separator. Halfway mobile separator. Horizontal separator. Up to 6 horizontal separations.




## 309SU/CU - 475MU/PU - 478MU/PU 319ZE - 329SU - 329CD

Side separator. Halfway separator. Halfway mobile separator. Horizontal separator. Up to 6 horizontal separations.





## 325LI/LE/PI

Side separator. Halfway separator. Halfway mobile separator. Horizontal separator. Up to 2 horizontal separations.





Horizontal Separator Part Number	X mm
SO11031	31
SO11052	52
SO11068	68



Side separator. Halfway mobile separator. Halfway separator. Horizontal separator. Up to 4 horizontal separations.  
Separation system with 2 slots or 3 slots.




Side separator. Halfway mobile separator. Halfway separator. Horizontal separator. Up to 4 horizontal separations.



Side separator. Halfway separator. Horizontal separator.  
In chains type H80 and H100, versions PC and PA, dimensions of inner compartments change according to the position of horizontal separators, due to the inner cover.




Side Separator. Halfway Separator. Horizontal Separator.  
*S1105F* designed to having a side of 5 slots and other side of 3 slots for many separations.



### 335LI/LE - 435MU/PU


Side separator. Halfway separator. Halfway mobile separator.  
Horizontal separator. Up to 4 horizontal separations.



Horizontal Separator Part Number	X mm
SO11031	31
SO11052	52
SO11068	68

### X36

Side separator. Halfway separator. Halfway mobile separator.  
Horizontal separator. Up to 4 horizontal separations.



Horizontal Separator Part Number	X mm
SO11031	31
SO11052	52
SO11068	68