HOW TO ORDER YOUR DISCONNECTOR PLUGS AND SOCKETS

If you have difficulties finding the correct stock code for your decontactor requirements, follow the service instruction to achieve a identification code. With the correct code (13 digits) our sales staff will easily determine our stock number.

3PS XX X XX X XX X X

Amp. rating	1	16A
	+ 16	16A
	3	32A
	+ 32	32A
	6	63A
	+ 63	63A
	+ 9	125A
	+ 2	200A
	+ include facility for pilots	
Type of device	D	Panel mounting socket
	P	Plug
	C	Cable connector
	A	Appliance inlet
	W	Wall box
Number of contacts	20E	2P+E
	30E	3P+E
	1NE	1P+N+E
	2NE	2P+N+E
	3NE	3P+N+E
Voltage	08	24V
	03	220/240V
	01	380/440V
	19	660V
	20	250V DC
2 pilot pins	P	
Self opening lid*	O	

Example:

3PS32D3NE01 means 32A 3P+N+E 380V/440V panel mount socket including pilot facility

*If no number, it is a self closing lid (standard)